



**4 Times Speeder Spindle
for Swiss CNC**

「IB・SPINDLE」

Suzuki Precion Co., Ltd.




Dramatically reduce your machining time with these IB • SPINDLE Speeders.

Specification


- Upgraded to a maximum guaranteed rotation speed of 40,000^{min-1}.




- Please use an ER11 collet chuck.



- Cutting tool overhang is amazingly 20mm shorter than a standard spindle.




- It only takes ONE WRENCH to install on your existing machines.



- No additional driving unit or transmitter needed.




- Helps to reduce your carbon footprint.




CSM4 – 02V1

L20E-VIII · IX Evolution / L20X Innovation




CSM4 – 03V1

A20VII Evolution / A20VII(A20-3F7) / A32VII Evolution
L20XII Innovation / L20VIII · IX · X · XII
L32VII · IX · X · XII M32III · V · VII · VIII Innovation
D25VII / VIII




CSM4 – 04V1

L12VII Innovation / L20EVIII · IX Evolution / L20X Innovation
L20XII Innovation / L20VIII · IX · X · XII
M16V · VII · VIII (U153B-Option)
M20 / M32 (Y265274-Option)




CSM4 – 05V1

L20X · XII Innovation / L20X · XII



CSM4 – 07V1

MC20



Install Information

- Cincom A20VII Evolution Line
- Cincom A32VII Evolution Line




- Cincom D25 VII · VIII

- Cincom MC20


- ▶ CSM4-03V1
- ▶ CSM4-04V1

- ▶ CSM4-03V1


- ▶ CSM4-07V1




Cincom L12VII Innovation Line




Cincom L20




Cincom L20EVIII · IX Evolution Line
Cincom L20X Innovation Line




Cincom L220VIII · IX · X · XII




Cincom L32VIII · IX · X · XII




Cincom M20III · V / M32III · V




Cincom M16V · VII · VIII



Cincom M32V · VII · VIII




It enables high-speed machining on both front and back cutting with the M20/M32 turret.



※Please purchase the holder from Citizen Machinery Ltd.


SSM4 – 01V1

SV12 / SV16 / SV20 / SV38R
SR16 / SR20 / SR20J / SR20RIV / SR32J / SR32J TypeN
SB12R / SB16R / SB20R
SW20 / SP20






SSM4 – 02V1

SB12R / SB16R / SB20R
SR10J / SR20J / SR16/20R / SR20R II / SR20R III / SR20R IV A/B
SR32J / SR32J TypeN / SR38TypeA/B
SW12R II / ECAS12/20 / SP20




SSM4 – 04V1

SW12R / SW20 / SV20R / SB16/20R
SR20J / SR20RIV / SR38 / SR38J




【Examples】




【Caution】


The screw sizes of SSM4-02V1 and SSM4-04V1 are different.




■ SB12R / 16R / 20R Type E/N/G




■ SB16R / 20R Type C




■ SR10J Type C





■ SR20J Type C/N




■ SR32J / 32J Type N




■ SR20RⅣ Type A/B




■ SR38 Type A/B




■ SW12R Ⅱ




■ SW20



■ SV12 / SV20 / SV32 / SV32J Ⅱ



■ SV38R



It enables high-speed machining on both front and back cutting with the SB&SR.

※Please purchase the 87700156 holder from star Micronics Co., Ltd.


87700156



SSM4-02V1


3290-Y3671-01A0

B0265-II / B0265B-II / B0266-II
B0325-II / B0325B-II / B0326-II




3290-Y681-01A0

B0265-II / B0265B-II / B0266-II / B0325-II / B0325B-II
B0326-II / SS267 / SS327 / SS267-5AX / SS327-5AX





3281-Z06231-01B0

S205A / S205 / S206




3220-Y7551-01A0

B073-III / B0123-III / B0203-III / B074-III / B0124-III / B0204-III
B075-III / B0125-III / B0205-III / B0126-III / B0206-III
P013 / P014 / P033 / P034 / S205 / S206




Oil mist lubrication is possible.




Install Information

■ SS267 / SS327
SS267-5AX
SS327-5AX




▶ 3290-Y681-01A0

■ B0265 II / B0265B-II
B0325-II / B0325B-II
B0266-II / 0326-II




▶ 3290-Y681-01A0
▶ 3290-Y3671-01A0

■ S205A / S205 / S206



▶ 33281-Z06231-01B0
▶ 3220-Y7551-01A0

■ B073-III / B074-III
B075-III / B0123-III
B0124-III / B0125-III
B0126-III / B0203-III
B0204-III / B0205-III
B0206-III




▶ 3220-Y7551-01A0

To keep it performing at its best,
follow these guidelines for attaching cutting tools.


THE PROPER WAY TO ATTACH THE IB · SPINDLE



Tighten the collet nut while the spanner holder is fixed.



When tightening the collet nut, do not tighten the collet nuts of the “other spindles” while the spanner holder is fixed. This may cause damage.



 Movie





Suzuki Precion Co., Ltd.

<https://www.precion.co.jp/english/>

113-2, Nojiri, Kanuma City, Tochigi

322-0251 Japan

TEL (81)289-65-6001

FAX (81)289-62-8084

【Contact us】

<https://www.precion.co.jp/english/#contact-form>



We reserve the right to make modifications without notice to improve the performance of our products.